

PFAFF

4240,
4250, 4260


Teileliste


List of spare parts


Liste des pièces détachées


Catalogo pezzi staccati


Lista de piezas de repuesto
































	98-694 843-00	93-414 034-77/451		98-694 845-00	93-414 032-09 (2x)		(3x)		48-020 804-32		93-414 032-82		93-414 032 81		93-414 032-08		93-414 034-76/451
---	---------------	-------------------	---	---------------	--------------------	---	------	---	---------------	---	---------------	---	---------------	---	---------------	---	-------------------

9341172336002

93-414 036-36/001



93-414 036-40/900

