





SINGER®

C440





Liste de pièces Lista de Piezas Parts List

A





No.	Part No.	Description
#1	68002594	Base Assy.
#2	68003396	Rear Cover Assy.
#3	68003442	Flap Assy.
#5	68002728	Handle Assy.
19	412423701	Thread Cutter
27	68002745	Screw Cap A
28	68002746	Screw Cap E
29	68002747	Screw Cap C
30	68002748	Screw Cap D

B





<u>No.</u>	<u>Part No.</u>	<u>Description</u>
#1	68003444	Front Cover Assy.
3	68001577	LED Light Cover (B)
4	68002754	Board Assy.
5	68002649	LED Board Assy. (A)
6	68002756	LED Board Assy. (B)
8	68002647	LCD
10	68002645	Touch Panel
13	68003445	Flat Cable
15	68002758	Membrane Switch (LCD)
16	68002759	Membrane Switch (Main)
17	68002760	MKS Board Assy.
20	68002651	Cameo
21	68002762	Extension Table Assy.

C C440 Version 1




C440 Version 2




No.	Part No.	Description
#1	68002763	Bobbin Winder Assy. V.1
#1	68005906	Bobbin Winder Assy. V.2
#2	68002764	Thread Tension Cover Assy.
11	412423701	Thread Cutter
12b	68001351	Rubber Ring V.2
20	68002696	Rubber Ring V.1
27	68001355	Bobbin Winder Switch Assy.

D




No.	Part No.	Description
#1	68003446	Thread Tension Ragulator Unit
3	68001586	Thread Tension Disc
15		Tension Release Pulse Motor
27	416396101	Thread Check Spring

E





No.	Part No.	Description
#1	68001661	Needle Bar Guide Assy.
#2	68002675	Needle Bar Assy.
#3	68002776	Z Link Bracket Unit
#4	68002778	Presser Foot Lifter Bracket Unit
#5	68002779	Thread Take-Up Lever Unit
6	68001677	Threader Hook Assy.
16	68002629	Needle Clamp Assy.
17	68002630	Needle Clamp Screw
27	68001706	Needle Bar Clank Rod Assy.
34	68001725	Presser Foot Lifter
35	68001730	Presser Foot Switch Assy.
41	68001733	Presser Bar
42	68002688	Presser Bar Guide Bracket
48	68002497	Presser Foot Thumb Screw
50	68002781	Presser Foot Holder
51	68002802	Zigzag Foot

F




No.	Part No.	Description
#1	68001341	Belt Tension Assy.
1	68002605	Upper Shaft Assy.
6	68001199	Upper Shaft Timing Pulley
7		Spring Pin
8	68001234	STS Slit
9	68001326	Spring Pin
10	68001328	Clutch Change Collar
11	68001331	Clutch Change Spring
12	68001333	Belt Wheel
14	416400501	Spring Pin
15	68002805	Hand Wheel
16		Timing Belt (Upper Shaft)
17	68001340	Timing Belt (Motor)



G



No.	Part No.	Description
#1	68002957	Needle Plate Assy.
#2	68002958	Bobbin Holder Unit
14	68001385	Bobbin Cover Plate
17	68001389	Bobbin




No.	Part No.	Description
#1	68001452	Feed Rocking Assy.
#2	68002959	Feed Assy.
#3	68001467	Hook Race Unit




No.	Part No.	Description
#1	68001499	F Pulse Motor Assy.
#2	68001527	Lower Shaft Assy.
#3	68001659	Bobbin Holder Stopper Assy.

J




<u>No.</u>	<u>Part No.</u>	<u>Description</u>
#1	68002960	Thread Cutter Assy.
8	412423701	Thread Cutter
21	68001411	Thread Cutter Switch Assy.

K



No.	Part No.	Description
#1	68002816	Z Pulse Motor Assy.
3	68001750	BH Switch Assy.
25	68001575	LED Light Cover (A)



L



No.	Part No.	Description
#1	68001766	Power Circuit Unit
#2	68001768	Power Socket Assy.
#3	68001785	Motor Assy.
1	68001767	Fuse
4	68001772	Controller Jack Assy.
6	68003476	C.P.U. Board Assy. V.1
6	68005907	C.P.U. Board Assy. V.2

L

M



<u>No.</u>	<u>Part No.</u>	<u>Description</u>
#1	68003306	Accessory Kit
1	620098796	Needle Set
2	68001389	Bobbin
3	68001808	Screw Driver for Needle Plate
4	68001823	Screw Driver (Large)
5	68001822	Stitch Ripper
6	68001824	Brush
7	68003477	Buttonhole Foot
8	68002823	Overcasting Foot
9	416713001	Zipper Foot
10	68002824	Blind Stitch Foot
11	416713101	Satin Stitch Foot
12	68002825	Quilting Foot
13	416713201	Button Sewing Foot
14	68002826	Open Toe Foot
15	68002828	Quilting Guide
16	68001826	Spool Net
17	68001820	Spool Stand
18	68001821	Thread Cap (Small)
19	412610701	Felt Washer
20	68001559	Thread Cap
22	68002829	Foot Controller
23	412157801	Power Cord (EU)
23	412157903	Power Cord (USA.CND) (120V)
23	412158002	Power Cord (ENG)